

APPLICATIONS

- Separation systems
- Isolation applications
- Viscous & corrosive media
- High-pressure applications
- High vibration application

FEATURES

- Large volume type design
- Flushed diaphragm
- Welded diaphragm
- Optional flushing ring
- Optional exotic materials



FLANGED WITH WELDED DIAPHRAGM SEAL- TMC29-2

Standard version

Seal type : -1...250 bar (Flange $\geq 1.5"$) /
4...250bar (Flanges $\frac{1}{2}"$ to $1"$)

Instrument connection : $\frac{1}{2}"$ NPT (F) / $\frac{1}{2}"$ BSP (F)

Sealing fluid : Silicon DC 200 [-40...205°C]

Process connection : Flange as per standard
between $\frac{1}{2}"$ to $4"$

Flange facing type : Flat Face / Raised Face /
Ring Type Joint

Wetted parts protection

Service temperature : 200°C max.

PTFE coating on Diaphragm : 100 Micron thick

Service temperature : 150°C max.

DESCRIPTION

General

Flange design : ANSI B16.5 / EN 1092-1 / BS-10

Storage temperature : -40...+65°C

Service temperature : 370°C max.

Weld joints : Welded Top Chamber with
Diaphragm and Flange

Material of construction

Sensing Element : Diaphragm

Diaphragm : AISI 316L SS / Monel 400 / Hastelloy
C-276 Inconel 600 / Titanium / Tantalum

Flange material : AISI 304SS / AISI 316 SS

Top Chamber material : AISI 304SS

Capillary : AISI 304 SS / AISI 316 SS

Armour : AISI 304 SS / AISI 316 SS / PVC

Remote distance : 0.25 Mtr. to 25 Mtr.

Filling liquids Vs Temperature range

Code	Fluid Name	Temperature Range
L1	Silicon DC 200	-40°C to 205°C
L2	Glycerin	10°C to 150°C
L3	Food Grade oil	-20°C to 140°C
L4	Syltherm 800	-40°C to 315°C
L5	Silicon DC 710	7°C to 371°C

ORDERING CODES

MODEL						TMC29-2
TMC29-2 Flanged welded diaphragm seal						
SEAL TYPE						R12
R12	-1...0...250 bar [Flange ≥ 1.5"]		R13	4...250bar [Flanges ½" to 1"]		
DIAPHRAGM						S03
S03	AISI 316L SS		S05	Monel 400	S10	Hastelloy C-276
S06	Inconel 600		S07	Titanium	S08	Tantalum
CHAMBER / FLANGE						S02
S01	AISI 304 SS		S02	AISI 316 SS	S03	AISI 316L SS
S05	Monel 400		S10	Hastelloy C-276	S07	Titanium
S08	Tantalum					
INSTRUMENT CONNECTION						P28
P28	½" NPT (F)		P23	¼" BSP (F)	P27	½" BSP (F)
P24	¼" NPT (F)					
PROCESS CONNECTION						XXX
XXX	As per Flange table					
FLANGE FACING						G1
G1	Serrated raised face		G2	Flat face	G3	Ring type joint face
G4	Tongue & Groove face					
SEALING FLUID						L1
XX	As per Filling liquid Vs Temperature Rating table					
EXECUTION						R1
R1	Direct		R2	Remote		
CAPILLARY MATERIAL						XX
S01	AISI 304 SS		S02	AISI 316 SS		
ARMOUR MATERIAL						XX
S01	AISI 304 SS		S02	AISI 316 SS	S16	PVC [Ambient ≤60℃]
REMOTE DISTANCE						XXXXX
XXXXX	500 mm (Min.) to 25000 mm (Max.)					
OTHER OPTIONS						XXX
E77	Dry Seal		E31	Material test certificate 3.1	E32	Material test certificate 2.2

Ordering Example : TMC29-2-R12.S03.S02.P28.F07.G1.L1.R1/XX.XX.XXXXX/XXX